

NICE ERA INTI 2 REMOTE

CODING INSTRUCTIONS



CODING VIA WORKING REMOTE

Only 1 & 2 Button NICE FOR-s remotes can be copied

1. Be within 3 meters of your installation
2. Press a button on your new remote control for 5 seconds
3. Pick up a remote already coded - Slowly press a button 3 times waiting 1 second between each press and pressing for about 1 second each time.
4. Press the same button on your new remote control & release.
5. Wait 10 seconds, your new remote control is coded.

CODING VIA A RECEIVER

1. Open the box of your receiver. It is located near the motors.
2. On the receiver circuit board, press & hold the coding button. The receiver LED lights. Release the button.
3. Press a button on your new remote control.
4. Release. The receiver LED goes off.
5. Wait one second. Press the same button on your new remote control.
6. Release. The receiver's LED flashes 3 times.
7. Wait 10 seconds, your new remote control is coded.