

CODE EZY SPRINT REMOTE DUPLICATOR

CODING INSTRUCTIONS

INTRODUCTION

This device is able to duplicate several types of remote control for gates, garage doors, barriers, which transmit in frequencies between 286 and 868MHz. Each button is independent, so it's possible to clone up to 4 different remote controls, even if they operate in different frequencies.



DUPLICATION

1. Press together buttons 1 and 2, until LED becomes green.
2. Release all buttons.
3. Press once the button where you wish to duplicate the original remote control.
4. Start to transmit by pressing and holding the button on the original remote control, keeping it at 10cm from this device. When duplication ends, LED flashes 2 times in case of fixed code, or 4 times in case of rolling code. Then LED becomes green and duplication procedure restart from point 3.

After duplication, each button should be pressed at least 2 times to assure that the gate or garage works correctly.