

TAU 250K SLIM REMOTE – RP

Remote to Receiver:

1. Push the Learn/Mode/PROG/P1 button on your receiver.
2. Push the button you wish to code on the new remote.

This should now be coded into your receiver.

Radio Receiver – When in learning mode LED D1 will turn red and D2 will turn Green. Both will turn off once coded.

D760M Receiver – Red LED will turn off in learning mode. Red LED will pulse and then stay on once coded.

Diamond – DL8 Led will turn Green in learning mode. LED will turn OFF and then ON to allow for further remotes to be coded. LED will pulse and then turn off.

Remote to Remote

You will need to be in close proximity to your receiver/controller to successfully code your new remote. You will be using your old remote to active the learn button on your receiver/controller.

Original Remote manufactured prior to March 2014.

1. On the old remote hold down button 1, then press button 2 – three times.
2. The green LED should stop flashing and remain ON for 1 – 2 seconds.
3. Once this happens release both buttons.
4. The green LED flashes to advise that remote programming is activated.
5. On the new remote press the button that you wish to code.

Note: It is recommended to use the same button that is currently used to operate on the old remote (this is to allow this new remote to be used to code other remotes in the future)

Original Remotes manufactured after March 2014

1. In the original remote control – press and hold down the button currently used to open your door.
2. The green LED should turn ON, then OFF, and then should start flashing.
3. Release the button once flashing. This remote should now be in Learn Mode.
4. On the New Remote Control, Press the same button as the Original Remote. This remote should now be synced to your opener.

Note: If you are using this remote to control more than one receiver in close proximity – it is recommended that you turn power off to all except the receiver you are currently coding.

