

# CODE EZY TILT REMOTE

## CODING INSTRUCTIONS

---



### CODING YOUR REMOTE

1. Open the new remote by unscrewing the screws at the back of the remote. Make sure not to lose the screws, as they are important
2. Gently pull apart at the key chain connection point - Open the existing remote battery cover to see the switches inside.
3. Making sure not to change the switches that form the code - the sequence of switches ON & OFF.
4. Duplicate this sequence into the new remote.
5. Close both remotes & test.

### LOST YOUR REMOTE

1. Locate the antenna wire hanging down the rear of the opener motor - Remove the motor cover on that side by unscrewing all of the relevant screws
2. Once removed locate the control board - on this will be a sequence of 8 dipswitches. Make sure not to change any of their positions - this is the code that you need.

FOLLOW 1 to 5 above from here.

