


# OMGATE

TRANSFORMING YOUR GATE SYSTEM WITH  
TODAY'S MOST ADVANCED CONTROL AND MANAGEMENT APP



HOW IT WORKS, EASY AS 1, 2, 3..



1

Install the Gate Controller  
on your garage door unit  
and control it with OmGate app.



2

Get the app  
[omgate.me/download](http://omgate.me/download)



3

With OmGate, the door will  
automatically open for you  
when you arrive.

● USER AND GATE MANAGEMENT ● EASY INSTALLATION ● RESIDENTIAL AND COMMERCIAL

ph: +61- 39558 6866 m: +61-447 212 869  
e: [sales@omgate.com.au](mailto:sales@omgate.com.au) w: [www.omgate.com.au](http://www.omgate.com.au)

## SPECIFICATIONS

### OMGATE DEVICE SPEC

Operating voltage:	7 to 35 Volt D.C. or 5 to 24 Volt A.C.
Current:	80 mA max.
Operating temperature:	-20 to +70 °C
Wireless frequency:	2.4 to 2.48 GHz
Transmission power:	7 dBm
LED Indicators:	Steady blue LED - Indicates power supply is working Blinking red LED - Indicates signal (pulse) was sent to gate LED is off - Indicates unit is off/faulty

### OMGATE APP SPECS

iOS Support:	Compatible with iPhone model 4S and higher, and iOS 7 and up
Android Support:	Compatible with most Android-supported phones from 2013 and later, and with Android 4.4 and higher.

# OMGATE

**ph:** +61-3 9558 6866 **m:** +61 447 212 869  
**e:** sales@omgate.com.au **w:** www.omgate.com.au

Copyright ©2015 OmGate. All rights reserved. OmGate logos and product names are registered trademarks of OmGate. No part of this document may be reproduced by any means, nor translated to any electronic medium without the written consent of OmGate. Information contained in this document is believed to be accurate and reliable, however, OmGate assumes no responsibility for its use. Specifications are subject to change without notice.